



HPX

STEP-BY-STEP PRODUCT PHOTO GUIDE



BEFORE



1 Clear area of contamination

Clear the substrate of any dust, dirt, and debris - ensuring the area is clean and prepared properly.



2 Carefully bed bandage

For any areas that are split you must use 75mm (450gsm) bandage tape. Apply some HPX to the surrounding area of the split. Bed the bandage tape over the split, and then use a consolidation roller to ensure the fibres are broken down - the bandage tape must be fully encapsulated so apply more HPX if required.



3 Work way around substrate

Work your way around the substrate and repeat the above instruction for any further areas that need repair.



4 Use roller to apply

Using a roller (either a Mohair roller or Lambswool roller) - apply the HPX liquid to the entire substrate (1.6kg - 1.8kg per sqm depending on substrate). You must ensure adequate HPX is used to ensure the substrate is covered entirely - with no substrate visible through the HPX.



5 Self leveling

The HPX will start to self level itself.

AFTER - Finished Result



Tricel Composites (GB)
Unit A Fox Way, Atkinson Street,
Leeds LS10 1PS, UK
Tel: +44 113 270 3133

Tricel Composites (NI)
Milltown Industrial Estate, Greenan Rd,
Warrenpoint, Newry BT34 3FN, UK
Tel: +44 28 4175 3738

www.triroof.co.uk